


## Netflix TV Software Update Instruction


Preparation works:

First of all, you must copy the correct software into the USB and put it in the root directory, don't create a new folder and put it in the new folder.

For example, you want to update the U55G6, you should copy the software of U55G6 into the USB, and put it in the root directory as below picture:



Then, rename this file name to "MstarUpgrade.bin":



You can update the software by follow steps:

- 1. Plug USB stick into TV's USB socket.**
- 2. Turn on TV, press MENU on remote then select "OPTION" –"UPGRADE"-"USB UPGRADE"  
Select "Yes" when confirmation message comes up.**
- 3. It will take about 5 minutes to upgrade the new software.**
- 4. After TV turns on by itself, it need to be reset , follow the installation guide on the screen, press exit to close the guide.**
- 5. Press Menu on remote, then press 3,1,3,8 and TV will go into factory setting.**
- 6. Press down arrow to select "reset all "and press OK.**
- 7. TV will turn on by itself and upgrade finishes.**